



Airflow Control, Air Barriers, and Energy

Dr John Straube, P.Eng.
University of Waterloo
Building Science Corporation



Introduction

- Energy and R-value
- Airflow Control vs Air Barriers
- Airflow and Energy
- Metrics and Measurement





Energy is important

- Slowing heat loss/gain through enclosures is important part of future buildings
- “High R” walls are required, new/retrofit
- But R-value is not a good measure for good enclosures

www.BuildingScience.com



R-value: ASTM C518

- FTC “Rule” R-value reported at mean temperature of 75 F
- Typical hot plate: 95F, cold plate 55F




FIG. 3 Apparatus with Two Heat Flux Transducers and One Specimen


www.BuildingScience.com








Factors influence Heat Flow

- Temperature
- Thermal bridging
- Insulation installation defects
- **Airflow**









Energy and Through-flow

- Easy to calculate energy from *through* flow
- Hard to quantify other terms

$$q = \frac{dm}{d\theta} c_o \cdot \Delta T \quad [1]$$


where θ represents time and

$\frac{dm}{d\theta}$ is the mass flow rate of the fluid (kg/s) per unit time,
 c_o is heat capacity of the fluid (J / (kg·K)), and
 and ΔT is the temperature difference (K).

www.BuildingScience.com



Airflow vs R-value



www.BuildingScience.com



bsc

Convection Loops

A: Air Loops Around Insulation

B: Air Loops Through Insulation

www.BuildingScience.com

Building AMERICA
U.S. Department of Energy

bsc



Convection Loops



- Small gaps in batt insulation on both sides
- closed circuit
- energy cost
- cold surfaces


Cold or Hot Weather

www.BuildingScience.com

Building AMERICA
U.S. Department of Energy







bsc

Summary

- R-value measures insulation
 - We need assembly values, as built
- Air barriers are good start
 - But *controlling* airflow is what is needed
- What you cant measure, you cant control
 - We need better metrics, then standards to follow
 - Material airtightness is not very useful

www.BuildingScience.com

Building AMERICA U.S. Department of Energy